

Specific cleaning notes for LITEX PIX

## Specific cleaning notes for LITEX PIX

In addition to our general cleaning guidelines, the following points for the printed surface are to be observed:

For typical regular cleaning using the wet method, we recommend lots of clean water at a maximum temperature of 50 degrees celsius and using a household mild cleaning agent (e.g. liquid dishsoap) without scouring agents. Mild glass cleaners can also be used.

Regardless of the cleaning method used (wet or dry, water, soap suds or glass cleaner) only soft cloths are to be used. If sufficient liquid is used then it is also possible to use soft sponges or rubber squeegees.

After great exposure to steam or humidity (e.g. showers), we recommend to wipe off the glass first with a soft drapery and let it dry for at least 2 minutes before cleaning it with a special cleaning material.

## Specific cleaning notes for LITEX PIX

Unsuitable and prohibited are scouring or abrasive cleaning agents and cloths.

Examples of unsuitable products:

- Scouring creams etc.
- Vinegar or acetic acids with more than 5% acid content
- Bleaching or oxidizing cleaners
- Scotch scouring pads, rough cloths etc.
- Blades, scrapers or knives made of metal or hard plastic
- Pointed or scratching utensils

Removal of residue from transport spacers or identifying labels is to be carried out using mild cleaning agents. Glass soiling is to be removed in typical wet method using lots of water, sponge, squeegee, chamois or household spray cleaners.